

Защиты перехода (GA 87 / GA 88)

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Россия +7(495)268-04-70

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Киргизия +996(312)-96-26-47

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Казахстан +7(7172)727-132

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93



Limitatore di sovrappressione

Overrange protector

E' un dispositivo di sicurezza completamente automatico contro sovrappressioni eccedenti il limite sopportabile dallo strumento. Al raggiungimento della pressione prefissata, la valvola chiude automaticamente e blocca il passaggio del fluido di processo allo strumento. Dopo la diminuzione della pressione di circa il 25% del valore di chiusura, la valvola si riapre ed il lo strumento viene reinserito.


Può essere di tipo a soffietto per regolazione a bassi campi da 200 mBar fino a 4 Bar con massima pressione di 100 Bar, o di tipo a pistone + o-ring per alti campi da 2 a 400 Bar con massima pressione di 400 Bar. I limitatori di pressione possono essere forniti sgrassati per uso su ossigeno, tarato e stampigliato e può essere inserito tra manometro e separatore.

It is a safety device completely automatic to protect the instrument from damage caused by overpressure exceeding the limit acceptable by the instrument. The valve close and block the process pressure to the preset value. After decrease of pressure below about 25% of the preset value, the valve opens and allow the circulation of process fluid again.

May be bellow type for set at low ranges from 200 mBar to 4 Bar with maximum pressure of 100 Bar, or piston + o-ring type for set at high ranges from 2 to 400 Bar with maximum pressure of 400 Bar.

The over-range protectors may be supplied degreased for oxygen use, calibrated and marked and may be use between pressure gauge and chemical seal .

GA87



Elemento sensibile: pistone + soffietto
Materiale: AISI 316
Connessioni: 1/2" NPT o GAS
Impiego: tutti i fluidi compatibili
Campi di regolazione: Campo 0,2 ÷ 4 Bar
Pressione massima: 600 Bar
Temperatura di lavoro: -40 ÷ +120°C.

Tipo a soffietto - Bellow type

Sensing Element: piston + bellow

Material: st. st. 316

Connections: 1/2" NPT or BSP


Use: all compatible fluids

Adjustable ranges: Range 0,2 ÷ 4 Bar

Maximum pressure: 600 Bar

Working temperature: -40 ÷ +120 °C.

GA88



Elemento sensibile: pistone + o-ring
Materiale: AISI 316 + viton
Connessioni: 1/2" NPT o GAS
Impiego: tutti i fluidi compatibili
Campi di regolazione: Campo 6 ÷ 16 Bar = Molla nr. 3
 10 ÷ 40 Bar = Molla nr. 4
 30 ÷ 80 Bar = Molla nr. 5
 60 ÷ 160 Bar = Molla nr. 6
 100 ÷ 400 Bar = Molla nr. 7

Pressione massima: 600 Bar
Temperatura di lavoro: -40 ÷ +120°C.

Tipo a pistone - Pistone type

Sensing Element: piston + o-ring

Material: st. st. 316 + viton

Connections: 1/2" NPT or BSP

Use: all compatible fluids

Adjustable ranges: Range 6 ÷ 16 Bar = Spring nr.3

10 ÷ 40 Bar = Spring nr. 4

30 ÷ 80 Bar = Spring nr. 5

60 ÷ 160 Bar = Spring nr. 6

100 ÷ 400 Bar = Spring nr. 7

Maximum pressure: 600 Bar

Working temperature: -40 ÷ +120°C.

COME ORDINARE:

Prego specificare: modello, attacco, taratura eventuali opzioni.

Esempio: modello GA88, 1/2"NPTM, 40Bar

HOW TO ORDER:

Please specify: model, connection, set, options if any.

Example: model GA88, 1/2"NPTM, 40Bar

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Россия +7(495)268-04-70

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Киргизия +996(312)-96-26-47

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Саранск (8342)22-96-24
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Казахстан +7(7172)727-132

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93